

## WINDOW INSTALLATION AND SEALING WITH ISOLINA FLAX INSULATION



1. Make a wall opening for the window frame.



2. Install stoppers in the frame and sealing spacers on top of the lower support beam.



3. Fasten the ISOLINA flax insulation on the window frame with a tack.



4. Tack one side of the plastic strip to the window frame, compress the ISOLINA flax insulation and tack the strip to the other side of the frame.



5. Install the window in the frame.



6. Remove the plastic strip.



7. Screw the window frame to the wall frame.



8. Small windows and ventilation shutters can be affixed with self drilling screws from the back of the post.



9. Check the sealing in the window corners.



10. No top & bottom support beams are needed for small window frames.

### INSTALLATION NOTES!

- ◆ Make the window opening for the frame according to the window size diagram!
- ◆ Check the window frame to wall frame alignment before final fixing!
- ◆ Use a wedge between the frames during fastening!
- ◆ Check the correct operation of the window during fastening!
- ◆ To complete the installation also install the cover plugs.